


DTO29-47-56

DESKTOP ORGANIZERS



IMPORTANT!

Assembly may require the assistance of another person.

Before you begin assembly:

READ THE DIRECTIONS all the way through one time. This will speed up the process and help you understand the sequence of steps.

COUNT THE PARTS AND HARDWARE before assembly. This ensures you have received all necessary parts before you begin.


TOOLS: You may need a Phillips head screwdriver, a medium slotted screwdriver or a plastic mallet. To protect your new furniture from damage during assembly, it is recommended to work on a carpeted surface.


In the event any parts are missing from this package, send your name, address, telephone number, and a description of the missing part(s) to: PARTS, Box 1420, Missoula, MT 59806 or call: 1-800-769-5693 or FAX 1-800-445-5281.


CAUTION: On assemblies requiring glue, make sure the unit is assembled correctly before gluing. Once this unit is assembled with glue, the manufacturer will not be responsible for damaged parts. Keep a damp cloth or sponge handy to wipe off excess glue.


To care for this furniture, simply wipe with a cloth dampened with glass cleaner containing ammonia-D.


PARTS DIAGRAM











HARDWARE




H1	DTO 29 - Rafix Flush Cam	909911	08 ea.
	DTO 47 - Rafix Flush Cam	909911	10 ea.
	DTO 56 - Rafix Flush Cam	909911	11 ea.
		000011	



H2	DTO 29 - Rafix Bolt	909925	8 ea.
	DTO 47 - Rafix Bolt	909925	10 ea.
	DTO 56 - Rafix Bolt	909925	11 ea.








16	DTO 29 – Shelf Divider	H10100	4 ea.
	DTO 47 – Shelf Divider	H10100	8 ea.
	DTO 56 – Shelf Divider	H10100	10 ea.

Using the Rafix System:


Insert the Rafix Cams into the appropriate holes. The flat edge of the cam should be facing the edge of the panel.


Slide Rafix Cams of the panel to be attached onto the corresponding posts.

When screwing post into hole, **Do Not** over tighten. Screw post down until bottom face of post flange just touches board surface.



Using a #3 Phillips screwdriver, turn the rotating portion of the Rafix Cam a 1/2 turn clockwise to secure. *IMPORTANT!* Do not exceed 1/2 turn when tightening cams. Turn 1/2 turn counterclockwise to disassemble and remove panel.









Insert 2 Rafix Flush Cams (H1) into each Side (A & B). Screw in 2 Rafix Bolts (H2) on each side as shown.



H1






#2

H2

Screw in 6
Rafix Bolts (H2)
into Top (C) as
shown in diagram.




NOTE: On the DTO56 there will be 1 additional Rafix Bolt on long edge.

NOTE: On the DTO56 there will be 1 additional Rafix Flush Cam on the top edge.



Tap in 6 Rafix Cams (H4) into Each of the 2 Adjustable Shelves (G). Tap Rafix Cams until fully seated.


NOTE: Position as shown, Rafix Cams cannot be repositioned if installed incorrectly.



Flat edges must be aligned H4


NOTE: On the DTO29 there will only be 4 Rafix Cams on each of the Shelves.

Position Right Side (B) onto Back (D) as shown. Turn Rafix Flush Cams (H1) to secure.




#6

Position Left Side (A) onto Back (D) and turn Rafix Flush Cams (H1) to secure.




#7

Position Top C onto Sides (A & B) and Back (D) as shown and turn the Rafix Flush Cams (H1) to secure




Select the position for each of the 2 Adjustable Shelves (G). Push in 2 shelf pins (H5) into Sides (A & B for for all dto units) and Back (D for DTO 47 and 56). Make sure the Shelf Pins are in the same position on all sides of unit for each shelf. Turn each of the Rafix Cams (H4) on the bottom of the shelves to secure.



#9

Slide on appropriate number of Shelf Dividers (H6) for your unit. Arrange in desired positions for your use.



Assembly of your Desktop Organizer is now complete.