

## **IMPORTANT!**

# Assembly may require the assistance of another person.

#### Before you begin assembly:

**READ THE DIRECTIONS** all the way through one time. This will speed up the process and help you understand the sequence of steps.

**COUNT THE PARTS AND HARDWARE** before assembly. This ensures you have received all necessary parts before you begin.


**TOOLS:** You may need a Phillips head screwdriver, a medium slotted screwdriver or a plastic mallet. To protect your new furniture from damage during assembly, it is recommended to work on a carpeted surface.

In the event any parts are missing from this package, send your name, address, telephone number, and a description of the missing part(s) to: PARTS, Box 1420, Missoula, MT 59806 or call: 1-800-769-5693 or FAX 1-800-445-5281.

**CAUTION:** On assemblies requiring glue, make sure the unit is assembled correctly before gluing. Once this unit is assembled with glue, the manufacturer will not be responsible for damaged parts. Keep a damp cloth or sponge handy to wipe off excess glue.

To care for this furniture, simply wipe with a cloth dampened with glass cleaner containing ammonia-D.

## PARTS DIAGRAM




#### Using the Rafix System:


Insert the Rafix Cams into the appropriate holes. The flat edge of the cam should be facing the edge of the panel.


Slide Rafix Cams of the panel to be attached onto the corresponding posts.

When screwing post into hole, **Do Not** over tighten. Screw post down until bottom face of post flange just touches board surface.



Using a #3 Phillips screwdriver, turn the rotating portion of the Rafix Cam a 1/2 turn clockwise to secure. *IMPORTANT!* Do not exceed 1/2 turn when tightening cams. Turn 1/2 turn counterclockwise to disassemble and remove panel.






#### Using the Minifix System:


Insert the Minifix Cams into the appropriate holes with the arrow facing outwards as shown.


When screwing post into hole, **Do Not** over tighten. Screw post down until bottom face of post flange just touches board surface.




Using the #2 Phillips screwdriver, rotate the Cam Devices a half turn clockwise until snug.


To disassemble, turn the Cam Devices counter-clockwise and remove panels.





Insert 7 Minifix Cams (H1) into Back Panel (D) with arrow facing outward, screw in 3 Minifix Bolts (H2) into back as shown. Insert 7 Minifix Cams into Fixed Shelf (G).






H4


**NOTE:** Rafix Housings cannot be repositioned if installed incorrectly.

**#5** Place Back (D) as shown. Position Fixed Shelf (G) onto Back. Turn Minifix Cams (H1) clockwise to secure.




# #6

Position right side (B) onto back (D) and Fixed Shelf (G) as shown. Turn Minifix Cams (H1) clockwise to secure.




#7

Position left side (A) onto back (D) and Fixed Shelf (G) as shown. Turn Minifix Cams (H1) clockwise to secure.




Select side that you would like the CD Rack on - right side or left side of unit. Use 4 flathead screws (H5) to install outside CD rack (H7) or (H8) as shown in the diagram.




## #10


#8

Screw in 3 Rafix bolts (H6) as shown into Shelf (G) and back (D) being sure to select holes closest to matching CD Rack installed in step 8. Slide Divider Panel (E or F) onto bolts and rotate Rafix Housing 1/2 turn clockwise to secure.











#13 Insert 12 Shelf Pins (H9) putting 6 on the Divider Panel (E or F) and 6 in matching holes on the Side Panel (A or B).





Press the 3 plastic Label Holder Moldings (H11) onto the front of each of the Adjustable Shelves (J).

