




BY  **IRONWOOD**

LFBB

BOOK BROWSER



IMPORTANT!

Assembly may require the assistance of another person.

Before you begin assembly:

READ THE DIRECTIONS all the way through one time. This will speed up the process and help you understand the sequence of steps.

COUNT THE PARTS AND HARDWARE before assembly. This ensures you have received all necessary parts before you begin.


TOOLS: You may need a Phillips head screwdriver, a medium slotted screwdriver or a plastic mallet. To protect your new furniture from damage during assembly, it is recommended to work on a carpeted surface.

In the event any parts are missing from this package, send your name, address, telephone number, and a description of the missing part(s) to: **PARTS, Box 1420, Missoula, MT 59806** or call: **1-800-769-5693** or **FAX 1-800-445-5281**.


CAUTION: On assemblies requiring glue, make sure the unit is assembled correctly before gluing. Once this unit is assembled with glue, the manufacturer will not be responsible for damaged parts. Keep a damp cloth or sponge handy to wipe off excess glue.

To care for this furniture, simply wipe with a cloth dampened with glass cleaner containing ammonia-D.

PARTS DIAGRAM



Side	01024941	2 ea.
------	----------	-------




Top Shelf	01024902	1 ea.
-----------	----------	-------




Upper Back	01024957	1 ea.
------------	----------	-------




Toeboard	01024972	2 ea.
----------	----------	-------




Bottom Shelf	01024921	1 ea.
--------------	----------	-------



Lower Back	01024960	1 ea.
------------	----------	-------



Front	01024980	2 ea.
-------	----------	-------



Divider	0124944	4 ea.
---------	---------	-------

HARDWARE



H1	Rafix Cam	909910	18 ea.
----	-----------	--------	--------



H2	Confirmat Screw	950100	4 ea.
----	-----------------	--------	-------




H3	Flush Rafix Cam - CCB	909911	28 ea.
----	-----------------------	--------	--------



H5	Raifix Bolt	909925	42 ea.
----	-------------	--------	--------




H6	Rafix Double Bolt	909926	4 ea.
----	-------------------	--------	-------



H7	Angle Bracket	401170	4 ea.
----	---------------	--------	-------



H8	Varianta Screw	988060	16ea.
----	----------------	--------	-------



H9	Wire Divider	490571	8ea.
----	--------------	--------	------



H10	Nylon dowel	909780	36ea.
-----	-------------	--------	-------




H11	2" Non-Skid Black Tape	298540	6 ea.
-----	------------------------	--------	-------

Using the Rafix System:



Insert the Rafix Cams into the appropriate holes. The flat edge of the cam should be facing the edge of the panel.

Slide Rafix Cams of the panel to be attached onto the corresponding posts.

When screwing post into hole, **Do Not** over tighten. Screw post down until bottom face of post flange just touches board surface.




Using a #3 Phillips screwdriver, turn the rotating portion of the Rafix Cam a 1/2 turn clockwise to secure. **IMPORTANT!** Do not exceed 1/2 turn when tightening cams. Turn 1/2 turn counterclockwise to disassemble and remove panel.




#1

Insert eight Rafix Cams (H1) into the Bottom Shelf (G) facing outwards and tap until fully seated in place as shown.


Important! The edge of the Rafix Cam must be aligned with the shelf edge. Rafix Cams are difficult to reposition if installed incorrectly.

**#2**


Attach Lower Back (J) to the Bottom Shelf (G) using two Confirmat Screws (H2). We will call this the "**Lower Assembly**".

**#3**


Insert ten rafix Cams (H1) into the Top (C) with the arrows facing out.

**#4**


Insert four flush rafix cams and 4 rafix double bolts (H6) into the Upper Back (D).

**#5**

Attach Upper Back (D) to the Top (C) using two Confirmat Screws (H2), being sure that the Cam holes of the Top (C) are opposite the Upper Back as shown. We will call this the "**Upper Assembly**".


**#6**

Insert 4 flush rafix cams (H3) into each dividers (L) as shown.




#7

Attach the four Dividers (L) into the Upper Back (D) of the Upper Assembly as shown, by placing the dividers onto the rafix bolts attached to the upper back. Turn cams to secure.




#8

Insert four flush rafix Cams (H3), and screw 6 rafix Bolts (H5) into each of the two Front Panels (K).




#9

Attach the two Front Panels (K) to the Upper Assembly as shown. Turn the flush rafix Cams to secure.




#10

Screw 13 Rafix Bolts (H5) into each of the two Sides (A) as shown.




#11



Attach the Upper Assembly to one Side (A) as shown. Tighten Cams on each of the Front Panels (K) the Top Shelf (C).

**#12**


Attach the Lower Assembly as shown. Tighten cams to secure.

**#13**

Attach the other Side Panel (A) as shown. Tighten the Cams to secure.


**#14**

Attach two Angle Brackets (H7) to each of the two Toeboards (F) as shown, using four Varianta Screws (H8).




#15


Attach the Toeboards (F) to the unit as shown, using four Varianta Screws (H8).

**#16**

Stand the unit upright. Insert the nylon spreada dowels (H10) and then Insert the eight Divider Wires (H9) into the top of the Bottom Shelf as needed.

**#17**

Clean the top surface of the Top Shelf (C). Attach six lengths of Friction Tape (H11) to the top (dry) surface of the Top Shelf, one in each section as shown.



Your Glacier Book Browser is now completely assembled and ready for use.