




# IRONWOOD

---

## CTR42 CTR48 CTR60

---

### ROUND CONFERENCE TABLES



#### **IMPORTANT!**

**Assembly may require the assistance of another person.**

**Before you begin assembly:**

**READ THE DIRECTIONS** all the way through one time. This will speed up the process and help you understand the sequence of steps.

**COUNT THE PARTS AND HARDWARE** before assembly. This ensures you have received all necessary parts before you begin.



**TOOLS:** You may need a Phillips head screwdriver, a medium slotted screwdriver or a plastic mallet. To protect your new furniture from damage during assembly, it is recommended to work on a carpeted surface.

In the event any parts are missing from this package, send your name, address, telephone number, and a description of the missing part(s) to: **PARTS, Box 1420, Missoula, MT 59806** or call: **1-800-769-5693** or **FAX 1-800-445-5281**.

**CAUTION:** On assemblies requiring glue, make sure the unit is assembled correctly before gluing. Once this unit is assembled with glue, the manufacturer will not be responsible for damaged parts. Keep a damp cloth or sponge handy to wipe off excess glue.

To care for this furniture, simply wipe with a cloth dampened with glass cleaner containing ammonia-D.

## PARTS DIAGRAM



Top – CTR42	06001301	1 ea.
Top – CTR48	06001401	1 ea.
Top – CTR60	06001501	1 ea.





R	#8 x 1.75" Flathead Screw	901114	6 ea.
---	------------------------------	--------	-------

Base – CTR42	06001311	1 ea.
Base – CTR48	06001411	1 ea.
Base – CTR60	06001511	1 ea.

### #1

Place the Top (C) onto a clean, carpeted surface center Base on Top. Secure the Base (K) to the Top (C) using six Long Flathead Screws (R) as shown.



### #2

With the assistance of another person, turn the unit upright. Adjust the Levelers when the unit is in place.

**The Round Conference Table is now fully assembled and ready for use.**

